Register your product and get support at
www.philips.com/welcome

Philips Sonicare Airfloss
100 SERIES

PHILIPS

35_020_4888_1_PictureRich-DFU_A6_v3.indd 1 15-03-11 11:5

1	Important Safeguards	3
2	What's in the box	6
3	Before first use	7
4	Preparing for use	8
5	Using	9
6	Auto off	10
7	Cleaning	11
8	Storing your AirFloss	12
9	Disposing or recycling at end of product life	13
10	Support	14

35_020_4888_1_PictureRich-DFU_A6_v3.indd 2 15-03-11 11:5

1 IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USE

DANGERS

To reduce the risk of electrocution:
- Do not place or store product where it can fall or be pulled into a bathtub, washbasin or sink.
- Do not place charger in or drop into water or other liquid, unplug the charger immediately if this should occur.
- After cleaning, make sure the charger is completely dry before you connect it to the mains.

WARNINGS

To reduce the risk of burns, electrocution, fire, or physical injury:
- DO NOT use alcohol or other cleaning fluids in the reservoir as it may be an ingestion hazard.
- DO NOT use attachments other than those recommended by the manufacturer.
- DO NOT plug the charger into an outlet with a voltage other than specified on the bottom of the charger. This product is designed to operate within a range of 100 to 240 volts. Voltage converters DO NOT Warranty voltage compatibility.
- DO NOT use hot water so as to avoid physical injury.
- DO NOT use the charger outdoors.
- DO NOT drop or insert any foreign objects into the reservoir.

35_020_4888_1_PictureRich-DFU_A6_v3.indd 3 15-03-11 11:5

- Never force the plug into an outlet; if the plug does not easily fit into the outlet, discontinue use.
- Keep the cord away from heated surfaces.
- Discontinue use if the nozzle, body, or charger body / cord appear damaged in any way. Refer to "Warranty and Service" for service or repair.
- This product contains no user-serviceable parts. Refer to "Warranty and Service" if AirFloss no longer works properly or needs repair.
- Use this product only for its intended use as described in this document or as recommended by your dental professional.
- This product is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- AirFloss is a personal care device and is not intended for use on multiple patients in a dental office or institution.
- Do not direct the spray under the tongue or into the ear, nose, eye, or other sensitive areas. See "Using AirFloss" for correct usage.
- Avoid applying excessive nozzle tip pressure.

35_020_4888_1_PictureRich-DFU_A6_v3.indd 4 15-03-11 11:5

MEDICAL WARNINGS

- Consult your dental professional before you use this product if you have had oral or gum surgery in the previous two (2) months.
- Contact your dental professional if excessive bleeding occurs after using this product or bleeding continues to occur after one (1) week of use.
- Discontinue use of this product and contact a physician/ dentist if discomfort or pain is experienced.
- This product complies with the safety standards for electromagnetic devices. If you have a pacemaker or other implanted device, contact your physician or the device manufacturer prior to use.
- Consult your physician if you have other medical concerns.

Electromagnetic fields (EMF)

This Philips product has been tested and is compliant with safety standards for electromagnetic devices. If handled properly and according to the instructions in this user manual, the product is safe to use.

SAVE THESE INSTRUCTIONS

35_020_4888_1_PictureRich-DFU_A6_v3.indd 5 15-03-11 11:5

2



A Guidance tip
B Nozzle
C Activation button
D Water reservoir and cover
E Handle
F Charge indicator
G Power on/off button
H Removable charger cover (select models)
I Charger

35_020_4888_1_PictureRich-DFU_A6_v3.indd 6 15-03-11 11:5

3 BEFORE FIRST USE

Charge AirFloss - Charge for 24 hours before first use. Charge indicator flashes green until fully charged. Rapid yellow flashing indicates charge is extremely low (fewer than 3 uses left). AirFloss is designed to last 2 weeks (or 14 uses) on a single charge.



35_020_4888_1_PictureRich-DFU_A6_v3.indd 7 15-03-11 11:5

4 PREPARING FOR USE

Preparing AirFloss - To use, attach nozzle, fill reservoir with water or mouthwash. After filling the reservoir, press the power on/off button to turn on, then press the activation button approximately 6 times or until spray is produced. The reservoir holds enough liquid for approximately 2 uses. Replace the nozzle every 6 months for optimal results.



35_020_4888_1_PictureRich-DFU_A6_v3.indd 8 15-03-11 11:5

5 USING

Use AirFloss - AirFloss is designed to be used on the outside of the teeth. Place the tip between teeth and apply gentle pressure. Press activation button to deliver a burst of air and water. Glide the guidance tip along the gum line until you feel it settle between the next two teeth. Press the activation button again and repeat for all spaces including behind your back teeth. Press power on/off button to turn power off after use.



35_020_4888_1_PictureRich-DFU_A6_v3.indd 9 15-03-11 11:5

6 AUTO OFF



35_020_4888_1_PictureRich-DFU_A6_v3.indd 10 15-03-11 11:5

7 CLEANING

Cleaning - Remove the nozzle and rinse with water. Use a cotton-tipped swab to wipe down the reservoir, if desired. Avoid getting foreign objects inside. The use of cleaning agents inside the device is not recommended. Do not clean in the dishwasher or any other sanitizing devices.



35_020_4888_1_PictureRich-DFU_A6_v3.indd 11 15-03-11 11:5

8 STORING YOUR AIRFLOSS

Storing - If AirFloss will not be used for an extended period of time, empty water from reservoir, press activation button until no spray is produced, unplug the charger, clean the product, and store it in a cool, dry place away from direct sunlight.



35_020_4888_1_PictureRich-DFU_A6_v3.indd 12 15-03-11 11:5

9 DISPOSING OR RECYCLING AT END OF PRODUCT LIFE

Please note this process is not reversible - The rechargeable battery inside the AirFloss cannot be replaced but can be removed for recycling. Please contact your local waste management for recycling requirements. Only remove the battery at the end of the product's life. Doing so earlier will destroy the product. Deplete the battery charge by repeatedly pressing the activation button until AirFloss can no longer produce any bursts of air. Observe basic safety precautions.



35_020_4888_1_PictureRich-DFU_A6_v3.indd 13 15-03-11 11:5

10 SUPPORT

LOCATING THE MODEL NUMBER
Look on the bottom of the unit for the model number (HX8181, HX8141, or HX8111).

SUPPORT
For product information and purchase, or for product support, please contact your local Philips Customer Care Center. The Customer Care Center in your area may be found in the Warranty and Service booklet you received with your product and at www.philips.com/Sonicare.

WARRANTY AND SERVICE
Philips warrants its products for 2 years after the date of purchase.

Defects due to faulty materials and workmanship will be repaired or replaced at Philips' expense provided that convincing proof of purchase in the qualifying period is provided.

WARRANTY EXCLUSIONS
What is not covered under the two-year warranty:
- Nozzle
- Damage caused by misuse, abuse, neglect, alterations or unauthorized repair
- Normal wear and tear, including chips, scratches, abrasions, discoloration or fading

35_020_4888_1_PictureRich-DFU_A6_v3.indd 14 15-03-11 11:5

IMPLIED WARRANTIES

ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTIES SET FORTH ABOVE. IN SOME STATES LIMITATIONS ON DURATION OF IMPLIED WARRANTIES DO NOT APPLY.

LIMITATION OF REMEDIES

IN NO EVENT SHALL PHILIPS OR ANY OF ITS AFFILIATED OR SUBSIDIARY COMPANIES BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, TORT, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, WITHOUT LIMITATION, LOSS OF SAVINGS OR REVENUE; LOSS OF PROFIT; LOSS OF USE; THE CLAIMS OF THIRD PARTIES INCLUDING, WITHOUT LIMITATION, DENTISTS AND DENTAL HYGIENISTS; AND COST OF ANY SUBSTITUTE EQUIPMENT OR SERVICES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES.

35_020_4888_1_PictureRich-DFU_A6_v3.indd 15 15-03-11 11:5

www.philips.com/Sonicare

©2011 Koninklijke Philips Electronics NV
(KPENV). All rights reserved.
PHILIPS and the Philips shield are
registered trademarks of KPENV.
Sonicare, the sonicare logo and Airfloss are
the trademarks of Philips Oral Healthcare
Inc. and/or KPENV.

Patents pending.
Reg. U.S. Pat. & Tm. Off.

4235 020 48881